TOOL NEEDED

- + Power Drill
- + 2 3/8" Hole Saw
- + 1/8" Drill Bit



* Instructions are applicable for all doors whether they are solid, hollow or metal.

INSTRUCTION INSTRUCTIONS

Step 1. Stick the provided transparent template on the outside of door at the desired installation position.

Step 2. With a 2 3/8" hole saw (drill bit attached inside), starting on the exterior side of door, drill two 3/8"

holes until the drill bit protrudes through the interior side of door at least 1/8". Then go to the inside and finish drilling the hole out.

Step 3. Drill two 1/8" holes for the retainer ring locking pins approximately 1/8" in depth, as indicated on

the template.

Step 4. Separate the locking ring by unscrewing from the main body.

Step 5. Insert main body into hole from the exterior side and place the pins in the holes.

Step 6. Secure snug and turn the locking ring until there is contact with the door surface.



Example only – NOT to Scale

WARRANTY Door Scope Products or/and Parts-For Both Model: DS/1000 & DS/2000

Innovative Productions, Inc. warrants

(A) That the product shall conform to the description contained herein and will be free from defects in material or workmanship for a period of (1) One year from delivery;

(B) That the product will be adequately packaged and labeled;

(C)That Innovative Productions, Inc. shall convey good and merchantable title to Distributor and that the product will be delivered free from any lawful lien, claim or encumbrance of nature, kind or character; and

(D) Innovative Productions, Inc. has fully complied with all applicable Federal, State and local laws, ordinances, orders, rules and regulations governing the sale or delivery of the products sold under the order except as provided above. Innovative Productions, Inc. makes no warranty, express or implied, concerning the product or the merchantability or fitness thereof for any particular purpose to Buyer.

For more information: Please call at 1-800-274- scope (7267) or e-mail at doorscope@yahoo.com