

# ASSA ABLOY

The global leader in  
door opening solutions

1. Drill Ø 1 1/4" hole x dp. 2 5/16" from top of threshold.
2. Grout strike into floor.

1. Mortise plate into surface.
2. Drill Ø 1 1/4" hole x dp. 2 3/16".
3. Drill two holes for plastic anchors or lead anchors to suit conditions.
4. Place anchors into holes.
5. Grout strike into floor.
6. Insert mounting screws.