



- ⑦ — SEE TEMPLATE 4569 FOR ELECTROLYNX DETAILS WHEN NEEDED.
- ⑥ — FOR 28- LEVER TRIM SEE TEMPLATE 4485, IF 88- LEVER TRIM IS USED (DOORS OVER 1 3/4" THICK), SEE TEMPLATE 4428 FOR TRIM DETAILS.
- ⑤ — SURFACE OF DOOR WHERE EXIT DEVICE IS TO BE APPLIED MUST BE FLUSH.
- ④ — SEE MASTER SHEET No. 4019 FOR AREAS REQUIRING REINFORCEMENTS.
- ③ — SEE STRIKE TEMPLATE FOR MOUNTING LOCATION OF STRIKE.
FOR 881 MONITOR STRIKE SEE TEMPLATE # 4386
- ② — WE RECOMMEND THAT ALL TAPPED HOLES BE DRILLED & TAPPED IN FIELD.
- ① — TOLERANCE ON ALL DIMENSIONS ±1/32".

SARGENT[®] Manufacturing Company 100 Sargent Drive New Haven, CT 06511	
DOOR MANUFACTURERS TEMPLATE: 12-2828 & 12-3828 WITH KNOB OR LEVER TRIM	RELEASE DATE 31 JAN 06
TEMPLATE NO. 4304 F	