

LFIC TAILPIECE & CORE INSTALLATION

STEP 1:


INSERT TAILPIECE AND INSTALL RETAINING CAP

Hager Core Requires Both Washers

STEP 2:

ROTATE CONTROL KEY 15° CW
& INSTALL INTO LEVER.

DO NOT FORCE INTO LEVER! IF
CORE DOES NOT FULLY INSERT,
REMOVE, CHECK TIMING AND TRY
AGAIN.



NOTE: FOLLOW TIMING INSTRUCTIONS (IF APPLICABLE) BEFORE
INSTALLING CORE.