


4500 TRIM TEMPLATE

STANDARD INSTALLATION FOR BE, CE, AND DT TRIM MODELS LHR AND RHR HANDING

(REV: 04)
T-ED00006



RIGHT HAND REVERSE (RHR) SHOWN

TRIM \varnothing CORRESPONDS TO
EXIT DEVICE \varnothing *

* SEE PAGE 1 OF THE TRIM
INSTALLATION INSTRUCTIONS
FOR ALIGNMENT DETAILS



HOLE LOCATIONS

PRIMARY DIMENSIONS SHOWN IN INCHES,
DIMENSIONS IN [] ARE MILLIMETERS.

