

RR42

Interlocking Rubber Ramp
12" Wide x 1" Tall



- Black Rubber
- 12" Wide x 1" Tall
- BHMA Certified to ANSI/BHMA A156.21 1,000 I.b. Load Test
- Supplied With Beveled Ends (End Slope = 1:2). Specify if Straight Cut is Required
- Rubber Ramp Sections May Be Combined With Aluminum Ramp Components for Higher

- Rises, or With 6" Flat Aluminum Interlocking Threshold #957 for Offset Conditions
- Black Silicone Adhesive Available to Secure Ramps Without Fasteners. Specify RR5007BL, Each Tube Will Secure 2 Ramps 12" Wide x 36" Long (6 Square Feet)
- Weight: 3.4 Lbs. /Ft.
- Maximum Length = 120"





I I I

INSTALLATION INSTRUCTIONS

- 1. Ramp may be cut in field to fit floor conditions.
- 2. Apply a solid bead of adhesive to underside of ramp at perimeter edges. Then apply several beads of adhesive in a criss-cross pattern to underside of ramp, so when set in place the adhesive spreads to thinly cover entire underside of ramp.

NOTE: Adhesive must be a type designed to bond rubber, concrete, wood, metal or other material to which ramp is being applied. (NGP black silicone adhesive #RR-5007BL is specifically designed for use to install this rubber ramp.)

3. Affix Rubber Ramp to desired location.
IMPORTANT NOTICE: DO NOT WALK ON OR APPLY WEIGHT TO RUBBER RAMP FOR 24 HOURS ALLOWING ADHESIVE TO FULLY CURE.





NGP MEMPHIS 4985 East Raines Road Memphis, TN 38118 FAX: (800) 255-7874 QUOTES: quotes@ngp.com ORDERS: orders@ngp.com **CARSON CITY** 3689 Arrowhead Drive Carson City, NV 89706