



FOR LHR DOOR



CUT OUT THIS SIDE ONLY, FOR WOOD DOORS THIS CUTOUT SHOULD BE 1 3/8" DEEP

PULL PLATE ϕ CORRESPONDS TO EXIT DEVICE ϕ


TRIM MOUNTING HOLE ON PULL SIDE, DRILL ϕ 1/2" FOR WOOD DOORS DRILL THIS HOLE THRU



ϕ

PULL SIDE OF DOOR

RHR DOOR EDGE OR STOP FACE



TRIM MOUNTING HOLE ON PUSH SIDE, DRILL ϕ 5/16" FOR METAL DOORS DRILL ϕ 1/2" FOR WOOD DOORS

TRIM SPINDLE HOLE ON PUSH SIDE, DRILL ϕ 5/8"

MARK HORIZONTAL CENTERLINE ON DOOR

PULL PLATE ϕ CORRESPONDS TO EXIT DEVICE ϕ

TRIM MOUNTING HOLE ON PUSH SIDE, DRILL ϕ 5/16" FOR METAL DOORS DRILL ϕ 1/2" FOR WOOD DOORS

PULL PLATE ϕ CORRESPONDS TO EXIT DEVICE ϕ

TRIM MOUNTING HOLE ON PUSH SIDE, DRILL ϕ 5/16" FOR METAL DOORS ONLY

ϕ

PUSH SIDE OF DOOR

HOLE LOCATIONS

PRIMARY DIMENSIONS SHOWN IN INCHES, DIMENSIONS IN [] ARE MILLIMETERS.

FOR RHR DOOR

