# Choosing the Right Hinge and the Right Number of Hinges

For your convenience, an interactive, easy to use hinge sizing calculator is available on our website, www.soss.com.

If the information you need is not on the online calculator or this chart, consult the factory.

To obtain the best performance from SOSS Invisible Hinges, it is recommended that the largest hinge model be used for the material thickness of the door.

Every door should be provided with at least one hinge for every 30 inches in height or portion thereof; however, more hinges may be required per chart below. For example, a 90" door needs three hinges and a 91" door needs four.

#### DIRECTIONS

After determining the weight and width of the door, draw a straight line through the door width and weight to line "A", as indicated in the example.

Continue with a horizontal line sideways from the point of intersection with line "A" until the door thickness is reached. Use the number of hinges and the model number indicated on this line

To use this chart as a working guide, we suggest that you photocopy this page.

lb

500

400

200

- 100

60

30

15

- 80

40

20

10

- 150

Hinge Number	114	314	205	106	100	101	303	103	203	204	208	212	216	218	220		
Door Material	_	METAL WOOD 8															
		9/16			1/2		11/16	3/4			1	11/8	13⁄8	13⁄4	2		
Minimum Door	mm			mm	15.88mm 12.70mm			mm			mm	mm	mm	mm	mm		
Thickness	14.29mm			15.88			17.46mm	19.05mm			25.40mm	28.56mm	34.93mm 13%	44.45mm	50.80mm		
														6			
														0			
															4		
														5			
														4	_		
															3		
													4				
														3			
Line A														Ŭ			
Ē												4	3				
			4	4						4	4	3					
										4		Ŭ					
						4											
Number of Hinges	4	4					4	4	4		3						
Required			3	3			4	4		3							
		3			4	3								2	2		
	3						3		3								
								3									
			2	2									2				
										2		2					
A					3						2						
Line A																	
	2	2				2	2	2	2								
					2												
Hindo Number																	
Hinge Number	114	314	205	106	100	101	303	103	203	204	208	212	216	218	220		

#### Door Width in Inches and Millimeters



## NOTE: For Fire-Rated Hinges, use formulas described on page 40.

## EXAMPLE

A wood door 30" wide, 200 lbs., with a thickness of 13/4" will require four #218 SOSS Invisible Hinges. The red line shows how the sizing and selection were determined from the hinge sizing chart.

The hinge sizing chart above has been developed to assist you in determining the correct size and number of hinges for your installation.

NOTE: For doors that exceed size/weight on this chart, consider using our new Hercules hinges shown on page 37.